

# Product Installation Guidelines & Scope of Use

Version 1.1, 27 August 2025, Page 1 of 4

# CliniMix® Bs Lead Safe Service Cartridges for CMV2 Low Flow - Pair

#### **PRODUCT CODES**

- 100.91.20.20

#### **SPECIFICATIONS**

- Designed to be used with CliniMix® CMV2 only.
- The Service Cartridge is complete with strainer, non-return valve and flow restrictor.
- Lead Safe<sup>™</sup> brass construction.\*

**IMPORTANT**: All CliniMix® isolating valves for CMV2 are tested and leave our premises in good working order.


\*Our Lead Safe™ product range is compliant with the Lead-Free Requirements of the NCC 2022 Vol. Three, Clause A5G4(2) and NSF/ANSI 372.

**WARNINGS:** Special attentions to be paid on notes, photos, images, or drawings of assembly steps marked with the warning symbol.




TECHNICAL DATA		
Working Pressure Range (kPa)	Min	20
	Max	500
Working Temperature Range (°C)	Min	5
	Max	85
Nominal Flow Rate (LPM)		4
Construction		Brass
Finish		Brass
NOTE O L. E		· · · · · · · · · · · · · · · · · · ·

**NOTE:** Galvin Engineering continually strive to improve their products. Specifications may change without notice.




#### **INSTALLATION**

**INSTALLATION COMPLIANCE:** Galvin Engineering products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable national and/or state standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.



#### 1. Close the mains and deinstall Spout

- Close off both (hot and cold) water mains or power main. Ensure water is not flowing when hand waving in front of the sensor.
- Loosen grab screw to unlock the spout. Pull and gently remove the spout.
- Removing the disinfection key cover plug might help with dettaching the faceplate in next steps.




#### 2. Remove the faceplate

- Loosen the grub screw shown on above picture.
- Unscrew the locking nut and remove.
  Remove the flange.
- Carefully remove the faceplate.
- Do not change the position of the backnut if not necessary.
- Disconnect sensors' and solenoids' cables connections.



#### 3. Ensure water is closed

Turn the isolating valve to 'CLOSE' position.



#### 4. Replace service cartridges

 Unscrew and replace both service cartridges using metric spanner 22mm.



### 5. Reassemble the unit

- Open both (hot and cold) water mains and check for leaks.
- Open both isolating valves and check for leaks.



**Note:** The flow might start from the inner part of the spout if the main power remained on.



## 6. Assemble and test

- Reassemble the unit by reversing steps 1 to 2.
- Test the fully assembled unit for correct operation

TROUBLESHOOTING		
PROBLEM	CAUSE	RECTIFICATION
Water is not flowing	Water mains closed	Open water main supply, ensure isolation valves are in open position
	Power mains off	Turn on the power

#### **WARRANTY**

Galvin Engineering products are covered under our Manufacturer's Warranty. Galvin Engineering products must be installed in accordance with the installation instructions and in accordance with AS/NZS 3500 and NCC Volume Three, relevant Australian Standards and local authorities applicable to product being installed. Water and electrical supply conditions must also comply to the applicable national and/or state standards, failing to comply with these provisions may void the product warranty and affect performance of the product.

Please visit <u>www.galvinengineering.com.au</u> to view the full warranty, our Installation Compliance and Maintenance & Cleaning information as well as any other additional information.

Within Australia: 1300 514 074 Outside Australia: P: +61 (0)8 9338 2344

F: +61 (0)8 9338 2340

sales@galvinengineering.com.au www.galvinengineering.com.au

ABN: 78 008 719 382

PERTH I SYDNEY I MELBOURNE I BRISBANE I ADELAIDE



