





Ezy-Wash® Pre-Rinse Tapware

PRODUCT CODE:

- TF83HJS
- TF83HJP



SPECIFICATIONS

- Galvin Specialised recommends the installation of strainers and pressure reducing valves prior to installing the pre-rinse unit to ensure clean consistent water supply. Debris or poor water quality could cause the trigger to seize or fail to seal.
- This pre-rinse unit has a 6 star WELS rating, the Pot Filler attachments are 0 star to allow fast pot filling.
- The hose on these units is not suitable for potable water and should only be used for washing down/ cleaning purposes.

TECHNICAL DATA

Inlet		1/2" BSP – Male
Outlet	TF83HJS	Trigger Spray
	TF83HJP	Trigger Spray & Pot Filler
Headworks	TF83HJS	Jumper Valve
	TF83HJP	Jumper Valve
Working Pressure Range (kPa)	Min	100
	Max	500
Working Temperature Range (°C)	Min	5
	Max	65
Nominal Flow Rate (LPM)	TF83HJS	3.5
	TF83HJP	15
Finish		Chrome

NOTE: Galvin Specialised continually strives to improve their products. Specifications may change without notice. Higher temperature or pressures could result in premature failure and void the manufacturer's warranty.

TOOLS REQUIRED

- Adjustable spanner
- Hex key
- Power drill

PRE-INSTALLATION


Body:

- If the mounting holes do not already exist, mark out and drill the holes in the bench, as shown.
- This model is a dual inlet unit requiring a hole diameters of 23mm - 26mm, 205mm apart. Ensure 70mm minimum between wall and hole center as shown "A".
- Maximum bench thickness is 55mm.


Wall Bracket:

- Mark out the three (3) holes for mounting the wall bracket assembly at a height of between 420mm min - 510mm max directly up from the bench. Cut out or drill as shown in the image. (Supplied fasteners may not be suitable for the mounting surface. If this is the case, suitable fasteners will need to be sourced by the installer)


Note: We recommend the wall bracket is installed at the maximum of 510mm. The wall bracket can be mounted lower at a height of up to 90mm below the circlip. However, the further it is mounted away from the circlip, the more the stability of the unit is compromised.



MOUNTING DETAILS




TF83HJS - Assembly



TF83HJP - Assembly

INSTALLATION


INSTALLATION COMPLIANCE: Galvin Specialised products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable national and/or state standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.



1. Measure and cut support rod

- Measure the distance between the wall mounting surface and the centre line of the drilled hole in the bench/trough (dimension “A”).
- Take dimensions “A” and subtract 16mm. This is the required length of the support rod (Required support rod length = A-16mm).
- Cut the support rod accordingly; ensure the threaded end is NOT cut off.


Note: Distance “A” must be no less than 70mm. The support rod length can be 70mm min. to 285mm max. (If it is more than 285mm, an extension support rod must be purchased)



2. Fit wall bracket


- Secure to the wall bracket to the wall.
- Supplied fasteners may not be suitable for the mounting surface. If so, suitable fasteners will need to be sourced.

Note: The wall flange must be mounted with three screws for stability and strength. This is critical, failure to do this may void the warranty.




3. Fit support rod

- If pot filler kit (TF83HJP) has been purchased, it must be attached to the pre-rinse unit prior to fitting the support rod to the riser. Refer to the installation instruction supplied with the Pot filler.
- Screw support rod into the riser hook and ensure it is not fully tightened.



4. Fit pre-rinse riser assembly

1. Fit compression nut to support rod, followed by the compression cone and locate the support rod into wall bracket.
2. Fit the pre-rinse riser assembly through the drilled hole on the bench.




TF83HJS

TF83HJP


5. Secure pre-rinse assembly

- Secure Pre-Rinse assembly with the supplied flanged back nut; ensure the sealing rubber washer is placed underneath the Pre-Rinse body flange.




6. Secure support rod

1. Fasten support rod securely against CP riser.
2. Tighten compression nut on wall bracket to secure the support rod. The rod is now rigid.




7. Fit hose

- Fit hose to the Pre-Rinse riser with a spanner.
- Ensure supplied fiber washer is fitted inside of hose nut.



TF83HJS



TF83HJP

8. Test unit

- Once all fittings have been tightened securely and the unit has been connected to the mains water, the unit must be tested for any leaks.

OPERATING INSTRUCTIONS

- The isolation or main taps must be turned OFF whilst the unit is not in use so that the unit is not under mains pressure when unsupervised. Flood damage may occur if a failure occurs whilst the unit is under mains pressure. (warranty is void in this instance).
- Galvin Specialised recommends the handpiece be removed periodically for servicing by a qualified plumber.

WARRANTY

The warranty set forth herein is given expressly and is the only warranty given by the Galvin Engineering Pty Ltd. With respect to the product, Galvin Engineering Pty Ltd makes no other warranties, express or implied. Galvin Engineering Pty. Ltd. hereby specifically disclaims all other warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

Galvin Engineering Pty Ltd products are covered under our manufacturer's warranty available for download from www.galvinengineering.com.au Galvin Engineering Pty Ltd expressly warrants that the product is free from operational defects in workmanship and materials for the warranty period as shown on the schedule in the manufacturer's warranty. During the warranty period, Galvin Engineering will replace or repair any defective products manufactured by Galvin Engineering without charge, so long as the terms of the Manufacturer's warranty are complied with.

The remedy described in the first paragraph of this warranty shall constitute the sole and exclusive remedy for breach of warranty, and Galvin Engineering Pty Ltd shall not be responsible for any incidental, special or consequential damages, including without limitation, lost profits or the cost of repairing or replacing other property which is damaged if this product does not work properly, other costs resulting from labour charges, delays, vandalism, negligence, fouling caused by foreign material, damage from adverse water conditions, chemical, electrical or any other circumstances over which Galvin Engineering has no control. This warranty shall be invalidated by any abuse, misuse, misapplication, improper installation or improper maintenance or alteration of the product

