



Ezy-Wash® Pre-Rinse Tapware

PRODUCT CODE:

- TF83WJS
- TF83WJP




WaterMark
AS/NZS 3718 Lic. WMKA0034
SAI Global



TF83WJS



TF83WJP



SPECIFICATIONS

- Galvin Specialised recommends the installation of strainers and pressure reducing valves prior to installing the pre-rinse unit to ensure clean consistent water supply. Debris or poor water quality could cause the trigger to seize or fail to seal.
- This pre-rinse unit has a 6 star WELS rating, the pot filler attachments are 0 star to allow fast pot filling.

TECHNICAL DATA

Inlet		½" BSP - Female
Outlet	TF83WJS	Trigger Spray
	TF83WJP	Trigger Spray & Pot Filler
Headworks	TF83WJS	Jumper Valve
	TF83WJP	Jumper Valve
Working Pressure Range (kPa)	Min	100
	Max	500
Working Temperature Range (°C)	Min	5
	Max	65
Nominal Flow Rate (LPM)	TF83WJS	3.5
	TF83WJP	15
Finish		Chrome

NOTE: Galvin Specialised continually strives to improve their products. Specifications may change without notice. Higher temperature or pressures could result in premature failure and void the manufacturer's warranty.

TOOLS REQUIRED

- Adjustable spanner
- Hex key
- Power drill
- Thread tape / sealant

PRE-INSTALLATION


Wall Spud

- This model is a dual inlet unit requiring two wall spuds. Spuds must be 1/2" BSP MI, 205 apart and protrude from the finished wall by no more than 15mm.


Wall Bracket:

- Mark out the three (3) holes for mounting the wall bracket assembly at a height of between 400mm min - 490mm max. Drill as shown in the image. (Supplied fasteners may not be suitable for the mounting surface. If this is the case, suitable fasteners will need to be sourced by the installer)


Note: We recommend the wall bracket is installed at maximum of 490mm. The wall bracket can be mounted lower at a height of up to 90mm below the circlip. However, the further it is mounted away from the circlip, the more the stability of the unit is compromised.



MOUNTING DETAILS




TF83WJS – Assembly



TF83WJP - Assembly

INSTALLATION


INSTALLATION COMPLIANCE: Galvin Specialised products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable national and/or state standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.



1. Measure and cut support rod

- Choose the appropriate option, as shown above, then measure distance 'A' or 'B'.
- Required support rod length (Option #1) = 77mm + A.
- Required support length (Option #2) = 77mm – B.
- If the wall is flush, A = B = zero. Therefore, cut the support rod at 77mm.
- Cut the support rod accordingly; ensure the threaded end is **NOT** cut off.


Note: Distance B cannot be greater than 17mm. If distance "A" is greater than 195mm, then an extension support rod must be purchased.



2. Fit wall bracket


- Secure the wall bracket to the wall. Supplied fasteners may not be suitable for the mounting surface. If this is the case, suitable fasteners will need to be sourced.

Note: The wall bracket must be mounted with three screws for stability and strength. This is critical and failure to do this may void the warranty.




3. Fit body flange

- Fit the body flanges to wall spud. Use thread tape or equivalent to ensure the connection does not leak.



4. Fit support rod

- If pot filler kit (TF83WJP) has been purchased, it must be attached to the pre-rinse unit prior to fitting the support rod to the riser. Refer to the installation instruction supplied with the pot filler.
- Screw support rod into the riser hook and ensure it is not fully tightened.




5. Fit upper riser to lower riser

- Remove protective cap from upper riser spindle.
- Fit the upper riser to the lower riser, ensure the sealing o-rings are inside the spindle.
- Tighten with new supplied grub screw.




It is critical that the grub screw point locates accurately into hole recess of mating part.

Failure to do so may result in damage and/or failure of the unit.




6. Fit Pre-Rinse riser assembly

1. Fit compression nut to support rod, followed by the compression cone and locate the support rod into wall bracket.
2. Fit the pre-rinse riser assembly to fitted body flanges. Ensure the sealing o-ring is inside the loose nut.



7. Secure support rod

1. Fasten support rod securely against riser.
2. Tighten compression nut on wall bracket to secure the support rod. The rod is now rigid.



8. Test unit

- Once all fittings have been tightened securely, connect the unit to the mains water.
- Turn on water and test the unit for any leaks.

WARNINGS

 For optimum performance it is recommended that the isolation or mains taps are turned off whilst the unit is not in use (overnight etc.), to ensure that the unit is not under mains pressure when unsupervised. Flood damage may occur if a failure occurs whilst the unit is under mains pressure (warranty is void in this instance).

 Galvin Specialised recommends that the handpiece is periodically serviced by a qualified plumber.

 **IMPORTANT:**

To seal the hose this unit uses Loctite 577 which is a thread sealant approved for use with potable water (AS/NZS 4020). If hose is to be removed for maintainance purposes, reseal the joints with Loctite 577, or an equivalent sealant compliant with AS/NZS 4020. Do not use thread tape to seal the hose connections, as this may cause the hose nut to become loosened over time and leak.

WARRANTY

The warranty set forth herein is given expressly and is the only warranty given by the Galvin Engineering Pty Ltd. With respect to the product, Galvin Engineering Pty Ltd makes no other warranties, express or implied. Galvin Engineering Pty. Ltd. hereby specifically disclaims all other warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

Galvin Engineering Pty Ltd products are covered under our manufacturer's warranty available for download from www.galvinengineering.com.au Galvin Engineering Pty Ltd expressly warrants that the product is free from operational defects in workmanship and materials for the warranty period as shown on the schedule in the manufacturer's warranty. During the warranty period, Galvin Engineering will replace or repair any defective products manufactured by Galvin Engineering without charge, so long as the terms of the Manufacturer's warranty are complied with.

The remedy described in the first paragraph of this warranty shall constitute the sole and exclusive remedy for breach of warranty, and Galvin Engineering Pty Ltd shall not be responsible for any incidental, special or consequential damages, including without limitation, lost profits or the cost of repairing or replacing other property which is damaged if this product does not work properly, other costs resulting from labour charges, delays, vandalism, negligence, fouling caused by foreign material, damage from adverse water conditions, chemical, electrical or any other circumstances over which Galvin Engineering has no control. This warranty shall be invalidated by any abuse, misuse, misapplication, improper installation or improper maintenance or alteration of the product.