

## CliniLever® Stainless Steel Lead Safe™ Gooseneck Sink Mixer

### PRODUCT CODES:

- TM-SNKGX



### SPECIFICATIONS

- Lead Safe™ stainless steel construction
- Clean hygienic design
- Low maintenance and easy to operate
- Smooth round designs to facilitate easy cleaning and help reduce dirt and bacteria growth.

**IMPORTANT:** All CliniLever® Taps are tested in accordance with AS/NZS 3718 and leave our premises in good working order.

### TECHNICAL DATA


Inlet	½" BSP – Female (Flexi-hoses)	
Outlet	Aerator	
Headwork	Ceramic Cartridge	
Working Pressure Range (kPa)	Min	50
	Max	500
Working Temperature Range (°C)	Min	5
	Max	80
Nominal Flow Rate (LPM)	5.92	
Construction	Stainless Steel	
Finish	Stainless Steel	

**NOTE:** Galvin Engineering continually strive to improve their products. Specifications may change without notice.



**DIMENSIONS**

- If the mounting hole does not already exist, mark out and drill the hole in the sink, as shown in the rough-in dimensions.

*Note: Before installation, all lines must be flushed. We recommend that a line strainer be installed prior to the CliniLever® Sink Mixer to eliminate any foreign material.*




**Rough-In Dimensions**




**INSTALLATION**

**INSTALLATION COMPLIANCE:** Galvin Engineering products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable national and/or state standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.




**1. Fit Mounting Hardware and Hoses**

- Screw in and tighten flexi-hoses. Insert the flexi-hoses as how the indications on the handle are shown. (Left hole for Hot and Right hole for Cold)
- Fully screw threaded rod as shown.




**2. Fit Tap**

- Ensure the sink mounting hole for the tap is as per the rough-in dimensions.
- Ensure the Bottom ring is present underneath the tap.
- Carefully fit the flexible hoses and threaded rod through the sink hole as shown.




**3. Secure Tap**

- Fit the mounting gasket and bracket as shown.
- Screw hex nut on threaded rod finger tight.



**4. Tighten Installation**


- Tighten the hex nut using the provided tool as shown.
- Ensure the tap body doesn't move on the sink once tightened.




**5. Connect Water and Test**

- We recommend the use of wall mounted isolating valves (not included).
- Ensure water supply lines are flushed before connecting.
- Connect the flexible hoses to the mains water as shown ensuring the hot and cold hoses are correct.
- Test the tap for leaks and correct operation.




**REMOVE & INSPECT FLOW REGULATING AERATOR**



- 1. Remove Flow Regulating Aerator Housing**
- Remove the flow regulating aerator housing as shown.




- 2. Remove & Inspect**
- Remove the flow regulating aerator.
  - Inspect for debris and clean. Replace if necessary.




- 3. Reassemble**
- Reverse steps 2 & 1 to reassemble ensuring the orientation is correct.
  - Test for leaks and correct operation.

**REMOVE & INSPECT CARTRIDGE**




**1. Remove Handle**

- Ensure the water supply is closed.
- Unscrew the handle and remove the grub screw.
- Remove the handle body



**2. Remove Cap and Retaining Nut**


- Unscrew the cap and retaining nut from the body



**3. Remove and Inspect Cartridge**

- Remove Cartridge
- Inspect for debris and clean. Replace if necessary.

Note: For cartridge replacement, use WaterMarked Standard/Universal 35mm Flat Cartridge. For more information, please contact Galvin Engineering



**4. Reassemble**

- Reverse steps 1 to 3 to reassemble ensuring the orientation is correct.
- Test for leaks and correct operation.

**TROUBLESHOOTING**

PROBLEM	CAUSE	RECTIFICATION
Tap is leaking	Cartridge damaged	Remove and inspect the cartridge, remove debris and/or replace if damaged
	Tap incorrectly installed	Follow the installation steps above when fitting the tap.
Tap has inconsistent flow	Blocked flow regulator	Follow the instructions above to remove flow regulator from the body and check for debris. Install an inline strainer to stop further blockages.
Tap moves on basin	Insufficiently tightened	Follow the steps above in relation to tightening the installation.
Water temperature is opposite to the handle markings	Inlet hoses connected incorrectly	Switch the hoses connection on the inlets
	Inlet hoses connected to wrong isolating valves	Switch the hoses connection on the isolating valves

**WARRANTY**

The warranty set forth herein is given expressly and is the only warranty given by the Galvin Engineering Pty Ltd. With respect to the product, Galvin Engineering Pty Ltd makes no other warranties, express or implied. Galvin Engineering Pty. Ltd. hereby specifically disclaims all other warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

Galvin Engineering Pty Ltd products are covered under our manufacturer’s warranty available for download from [www.galvinengineering.com.au](http://www.galvinengineering.com.au) Galvin Engineering Pty Ltd expressly warrants that the product is free from operational defects in workmanship and materials for the warranty period as shown on the schedule in the manufacturer’s warranty. During the warranty period, Galvin Engineering will replace or repair any defective products manufactured by Galvin Engineering without charge, so long as the terms of the Manufacturer’s warranty are complied with.

The remedy described in the first paragraph of this warranty shall constitute the sole and exclusive remedy for breach of warranty, and Galvin Engineering Pty Ltd shall not be responsible for any incidental, special or consequential damages, including without limitation, lost profits or the cost of repairing or replacing other property which is damaged if this product does not work properly, other costs resulting from labour charges, delays, vandalism, negligence, fouling caused by foreign material, damage from adverse water conditions, chemical, electrical or any other circumstances over which Galvin Engineering has no control. This warranty shall be invalidated by any abuse, misuse, misapplication, improper installation or improper maintenance or alteration of the product.