



THE MODEL 190.95.90.90 SHOWER TEST KITS GUIDE THE WATER TO A FLOOR DRAIN OR CONTAINMENT BUCKET.

ASSEMBLY INSTRUCTIONS:

1. CONNECT THREE-PIECE ROD ASSEMBLY AT THE COUPLINGS (CEMENT IF DESIRED).
2. INSERT THE RING IN THE FUNNEL FOLD.
3. INSERT RING HOOKS INTO THE TWO HOLES OF THE GRAB POLE (AS SHOWN).
4. PLACE THE SUPPLIED COLLECTION BUCKET UNDER THE FUNNEL AND ACTIVATE THE SHOWER FOR 6 SECONDS.
5. IF THE WATER LINE IS BELOW THE BLACK LINE ON THE BUCKET THEN THE SHOWER FLOW RATE IS NON-COMPLIANT.
6. MEASURE THE TEMPERATURE OF THE WATER USING THE SUPPLIED THERMOMETER. THE TEMPERATURE RANGE IS RECOMMENDED TO BE 16°C - 38°C.



DISTRIBUTED BY:



410 VICTORIA RD MALAGA WA
 ABN: 78 008 719 382
 +61 8 9338 2344 FAX: +61 8 9338 2340
 EMAIL: sales@galvinengineering.com.au
 WEBSITE: www.galvinengineering.com.au

ECN NO.	REVISED PER	BY:	MODEL(S)	PART NUMBER
	ECN: 5161	MJ	190.95.90.90	
DRAWN:	DATE:	CHK'D:	GALVINSAFE SHOWER & EYE WASH	REVISION
CLF	3/93	FV	TESTING KIT, AS COMPLIANT (HAWS)	5
APPROVED:	DATE:	SCALE:	DRAWING TYPE:	SIZE:
FV	01/30/17	1:1	INSTALLATION	A
				SHEET 1 OF 1