

Product Installation Guidelines

Version 1.1, 15th October 2024 Page 1 of 7 Document No: 001.00.40.05

GalvinAssist[®] Lead Safe™ Basin Mixer



For WaterMark information, refer to 113.12.00.XX.



113.42.61.03 - Long Flared Handle H&C - Black 113.42.63.03 - Long Flared Handle H&C - Aqua Blue 113.42.64.03 - Long Flared Handle H&C - Apple Green 113.42.65.03 - Long Flared Handle H&C - Ruby Red 113.42.66.03 - Long Flared Handle H&C - Coral 113.42.67.03 - Long Flared Handle H&C - Steel Blue

113.42.41.03 - Long Pin Handle H&C - Black 113.42.43.03 - Long Pin Handle H&C - Aqua Blue 113.42.44.03 - Long Pin Handle H&C - Apple Green 113.42.45.03 - Long Pin Handle H&C - Ruby Red 113.42.46.03 - Long Pin Handle H&C - Coral 113.42.47.03 - Long Pin Handle H&C - Steel Blue

113.42.20.03 - Long Paddle Handle H&C 113.42.20.04 - Long Paddle Handle W&C

BRUSHED CARBON FINISH

113.52.62.03 - Long Flared Handle H&C

113.52.42.03 - Long Pin Handle H&C - White

113.52.20.03 - Long Paddle Handle H&C

113.42.51.03 - Short Flared Handle H&C - Black 113.42.53.03 - Short Flared Handle H&C - Aqua Blue 113.42.54.03 - Short Flared Handle H&C - Apple Green 113.42.55.03 - Short Flared Handle H&C - Ruby Red 113.42.56.03 - Short Flared Handle H&C - Coral 113.42.57.03 - Short Flared Handle H&C - Steel Blue

113.42.31.03 - Short Pin Handle H&C - Black 113.42.33.03 - Short Pin Handle H&C - Aqua Blue 113.42.34.03 - Short Pin Handle H&C - Apple Green 113.42.35.03 - Short Pin Handle H&C - Ruby Red 113.42.36.03 - Short Pin Handle H&C - Coral 113.42.37.03 - Short Pin Handle H&C - Steel Blue

113.42.10.03 - Short Paddle Handle H&C 113.42.10.04 - Short Paddle Handle W&C

113.52.52.03 - Short Flared Handle H&C

113.52.32.03 - Short Pin Handle H&C - White

113.52.10.03 - Short Paddle Handle H&C

SPECIFICATIONS

- Chrome plate and brushed carbon finish for easy cleaning and durability.

- Simple servicing and readily available parts.
- Quality controlled. Every tap is tested.
- Lead Safe™ brass construction*.

IMPORTANT:

*Our Lead Safe™ product range is compliant with the Lead Free Requirements of the NCC 2022 Vol. Three, Clause A5G4(2) and NSF/ASNI 372. ** Any flow controller incorporated in the outlet to be tightened to prevent removal by hand. As Per AS3718

WARNINGS: Special attentions to be paid on notes, photos, images, or drawings of assembly steps marked with the warning symbol.



TECHNICAL DATA				
Inlet		1/2" BSP – Female (Flexi-hoses)		
Outlet		Aerated		
Headworks		Ceramic Disc		
Working Pressure Range (kPa)	Min	150		
	Max	500		
Working Temperature Range (°C)	Min	5		
	Max	60		
Nominal Flow Rate (LPM)		4.07		
Construction		Lead Free Brass		
Finish		Chrome / Brushed Carbon		
NOTE: Galvin Engineering continually strive to improve their products. Specifications may change without notice				

TOOLS REQUIRED

- Power Drill
- AF11 Spanner (Supplied)

PRE-INSTALLATION

- Before installation, all lines must be flushed.
- Galvin Engineering recommends the installation of strainers and pressure reducing valves (when necessary) to ensure clean consistent supply. Debris or poor water quality could affect the performance of the unit.
- If the mounting hole does not already exist, mark out and drill the holes on the bench, as shown in rough-in dimensions.



Product Installation Guidelines

DIMENSIONS 195 168 119 185 168 110 110 93 Ø40 07 Ø40· 4 4 40 MAX 40 MAX Ø50 🛏 Ø50 🛏 Ż 125 125 113.42.6X.XX & 113.52.6X.XX 113.42.5X.XX & 113.52.5X.XX Short Flared Handle Long Flared Handle 200 · 168 168 118 T 0 158 154 110 110 93 Ø40· 93 Ø40-4 40 MAX • Ø50 🛏 40 MAX • Ø50 🛏 t 1 125 125 113.42.4X.XX & 113.52.4X.XX 113.42.3X.XX & 113.52.3X.XX Long Pin Handle Short Pin Handle 192 168 168 118 0 0 169 157 110 110 93 93 Ø40· Ø40-4 7 4 7 40 MAX 40 MAX - Ø50 -Ø50 🛏 125 125 113.42.2X.XX & 113.52.2X.XX 113.42.1X.XX & 113.52.1X.XX Long Paddle Handle Short Paddle Handle

INSTALLATION

INSTALLATION COMPLIANCE: Galvin Engineering products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable national and/or state standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.





5. Connect Water and Test

- We recommend the use of wall mounted isolating valves (not included).
- Ensure water supply lines are flushed before connecting.
- Connect the flexible hoses to the mains water ensuring the hot and cold hoses are correct.
- Test the tap for leaks and correct operation.

REMOVE & INSPECT FLOW REGULATING AERATOR



1. Remove Aerator Housing

- Remove the flow regulating aerator housing as shown.



2. Reassemble

- Reverse step 1 to reassemble ensuring the orientation is correct.
- Test for leaks and correct operation.

REMOVE & INSPECT CARTRIDGE



TROUBLESHOOTING			
PROBLEM	CAUSE	RECTIFICATION	
Tap is leaking	Cartridge damaged	Remove and inspect the cartridge, remove debris and/or replace if damaged	
	Tap incorrectly installed	Follow the installation steps above when fitting the tap.	
Tap has inconsistent flow	Blocked flow regulator	Follow the instructions above to remove flow regulator from the body and check for debris. Install an inline strainer to stop further blockages.	
Tap moves on basin	Insufficiently tightened	Follow the steps above in relation to tightening the installation.	
Water temperature is opposite to the handle markings	Inlet hoses connected incorrectly	Switch the hoses connection on the inlets	
	Inlet hoses connected to wrong isolating valves	Switch the hoses connection on the isolating valves	

WARRANTY

Galvin Engineering products are covered under our Manufacturer's Warranty. Galvin Engineering products must be installed in accordance with the installation instructions and in accordance with AS 3500 and NCC Volume Three, relevant Australian Standards and local authorities applicable to product being installed. Water and electrical supply conditions must also comply to the applicable national and/or state standards, failing to comply with these provisions may void the product warranty and affect performance of the product.

Please visit www.galvinengineering.com.au to view the full warranty, our Installation Compliance and Maintenance & Cleaning information as well as any other additional information.

Within Australia: 1300 514 074 Outside Australia: P: +61 (0)8 9338 2344 F: +61 (0)8 9338 2340 sales@galvinengineering.com.au www.galvinengineering.com.au ABN: 78 008 719 382 PERTH I SYDNEY I MELBOURNE I BRISBANE I ADELAIDE

