

Product Installation Guidelines

Version 1, 9 July 2024, Page 1 of 3 Document No.: 001.00.30.04

Vandal Resistant CP-BS Lead Safe[™] J/V Hose Taps





PRODUCTS			
Item Code	Description		
174.42.02.01	Vandal Resistant CP-BS Lead Safe™ J/V Hose Tap - Cold		
174.42.02.02	Vandal Resistant CP-BS Lead Safe™ J/V Hose Tap - Hot		

SPECIFICATIONS

- High quality chrome finish for easy cleaning and hygiene maintenance.
- Vandal resistant handle featuring a locking ring to secure the handle to the spindle which may only be removed using the key provided.
- Australian Made; therefore, spare parts and support are available locally, reducing costs of down time on maintenance
- Lead Safe™ brass construction.*

IMPORTANT: All vandal resistant taps are tested in accordance with AS/NZS 3718 and leave our premises in good working order.

*Our Lead Safe™ product range is compliant with the Lead Free Requirements of the NCC 2022 Vol. Three, Clause A5G4(2) and NSF/ANSI 372.
**Any flow controller incorporated in the outlet to be tightened to prevent removal by hand. As Per AS3718.


WARNINGS: Special attentions to be paid on notes, photos, images, or drawings of assembly steps marked with the warning symbol.



TECHNICAL DATA				
Inlet	G 1/2" - Male			
Outlet	G 3/4" - Male			
Headwork	Jumper Valve			
Working Pressure Range (kPa)	Min	100		
Working Fressure Range (KFa)	Max	500		
Marking Temperature Banga (9C)	Min	5		
Working Temperature Range (°C)	Max	65		
Finish	Chrome			

NOTE: Galvin Engineering continually strive to improve their products. Specifications may change without notice.


PRE-INSTALLATION 🛕



- Before installation, all lines must be flushed.
- Galvin Engineering recommends the installation of strainers and pressure reducing valves (when necessary) to ensure clean consistant supply. Debris or poor water quality could affect the performance of the unit.


TOOLS REQUIRED

- Spanner or adjustable crescent
- Thread / sealant tape



INSTALLATION

INSTALLATION COMPLIANCE: Galvin Engineering products must be installed in accordance with these installation instructions and in accordance with AS/NZS 3500, the PCA and your local regulatory requirements. Water and/or electrical supply conditions must also comply to the applicable national and/or state standards. Failing to comply with these provisions shall void the product warranty and may affect the performance of the product.



1. Fit tap assembly

Fit tap assembly as shown ensuring thread tape/sealant is used.



2. Testing

 Once fitted turn on water and check for leaks and correct operation.

TROUBLESHOOTING				
PROBLEM	CAUSE	RECTIFICATION		
Water is not flowing or inconsistent flow.	Dirt in the cartridge / water supply not on.	Remove debris. Install an inline strainer to stop further blockages. Ensure water supply is turned on.		
Continous flow of water.	Top assembly cartridge loose or internally obstructed or damaged.	Remove cartridge, clean with water and re-grease spindle if required.		

WARRANTY

Galvin Engineering products are covered under our Manufacturer's Warranty. Galvin Engineering products must be installed in accordance with the installation instructions and in accordance with AS 3500 and NCC Volume Three, relevant Australian Standards and local authorities applicable to product being installed. Water and electrical supply conditions must also comply to the applicable national and/or state standards, failing to comply with these provisions may void the product warranty and affect performance of the product.

Please visit www.galvinengineering.com.au to view the full warranty, our Installation Compliance and Maintenance & Cleaning information as well as any other additional information.

Within Australia: 1300 514 074 Outside Australia: P: +61 (0)8 9338 2344

F: +61 (0)8 9338 2340

sales@galvinengineering.com.au www.galvinengineering.com.au

ABN: 78 008 719 382

PERTH | SYDNEY | MELBOURNE | BRISBANE | ADELAIDE



